



P.I. Engineering X-Keys Installation Guide

DEVICE INSTALLATION

Install the P.I. Engineering X-Keys device in any USB port and install the provided MacroWorks software.

DEVICE CONFIGURATION

The X-Keys device can be configured as follows:

- 1) Click the MacroWorks icon in the tray and select the type of device installed from the context menu in order to display the Device Configuration graphic and enter edit mode as noted by the flashing green led on some devices.
- 2) Click on the specific key you want to configure in order to display the Record/Edit Macro dialog.
- 3) In the Record/Edit Macro dialog
 - a. Press and release the key combination that you want to emulate.
 - b. Click on the 'Insert' menu and select 'Key Down'.
 - c. Click on the 'Insert' menu and select 'On Release' to display the 'Key Up Macro pane
 - d. Click in the Key Up Macro pane and press and release the same key combination that was pressed in the upper Key Down Macro pane.
 - e. Click on the 'Insert' menu and select 'Key Up'.
 - f. Click 'Ok' to end the macro recording.
- 4) Repeat from Step 2 for any other keys to configure.
- 5) Close the Device Configuration graphic to end edit mode.

VCOM CONFIGURATION

Hot Keys can be configured using the VCOM System Administration application as follows:

- 1) Open the Client Configuration dialog by clicking the 'Client Configuration' button
- 2) Select the VCOM Control Panel client with which the X-Keys device will be used and open the Selector Assignments dialog by clicking the 'Selector Assignments' button.
- 3) In the Assigned Selectors pane, click the selector for which a Hot Key is to be associated and select the 'Hot Key' button.
- 4) In the Selector Hot Key dialog, specify whether Ctrl, Alt and/or Shift are required to be pressed, select the Key from the drop down and then click 'OK' to save the Hot Key selection.
- 5) Repeat from Step 3 for any other selectors to configure.
- 6) Press 'OK' to save the Selector Assignments.